


DE9900 DATASHEET

SLSC RTI MODULE DSUB68



 DEICO

Contents

DESCRIPTION.....	1
HARDWARE OVERVIEW	1
Hardware Specifications	1
Electrical.....	1
Physical.....	1
Environmental.....	1
SIGNAL CONNECTIONS.....	2
XP2 Connector Pinout	2
XP3 Connector Pinout	3
JR1 Connector Pinout.....	3
JR2 Connector Pinout.....	4
CONFIGURATION.....	4

DESCRIPTION

DE9900 SLSC RTI Module DSUB68 is a rear transition interface which carries signals from SLSC form factor to a DSUB68 connector and a power header in order to allow the harness process. It also contains strain relief accessories to protect the cable from bending.

Areas of application include:

- ⇒ HIL Testing
- ⇒ Signal Transition

HARDWARE OVERVIEW

Hardware Specifications

Electrical

Specification	Minimum	Typical	Maximum
Number of Power Transitions	—	8	—
Number of Signal Transitions	—	32	—
Carried Voltage @ DSUB68	—	—	100V
Carried Current @ DSUB68	—	—	1A
Carried Voltage @ Power Header	—	—	250V
Carried Current @ Power Header	—	—	14A

Physical


Specification	Typical	Notes
Dimensions	101.86mm x 30.22mm	SLSC Standard Dimensions
DSUB68 Connector	DSUB68	MPN: 2-5174339-5
Power Header	HEADER	MPN: 1722991108

Environmental

Specification	Condition	Value
Operating Humidity	Relative, non-condensing	10% - 90%
Storage Humidity	Relative, non-condensing	5% - 95%
Operating Temperature	Forced-air cooling from chassis	0°C - 40°C
Storage Temperature	Non-operational	-40°C - 85°C

SIGNAL CONNECTIONS

XP2 Connector Pinout




XP2 Connector Pin Assignments

Row	z	a	b	c	d	e	f
1	GND	SIG_0	GND	-	SIG_1	GND	GND
2	GND	SIG_2	GND	-	SIG_3	GND	GND
3	GND	GND	GND	GND	GND	GND	GND
4	GND	SIG_4	GND	-	SIG_5	GND	GND
5	GND	SIG_6	GND	-	SIG_7	GND	GND
6	GND	GND	GND	GND	GND	GND	GND
7	GND	SIG_8	GND	-	SIG_9	GND	GND
8	GND	SIG_10	GND	-	SIG_11	GND	GND
9	GND	GND	GND	GND	GND	GND	GND
10	GND	SIG_12	GND	-	SIG_13	GND	GND
11	GND	SIG_14	GND	-	SIG_15	GND	GND
15	GND	SIG_16	GND	-	SIG_17	GND	GND
16	GND	SIG_18	GND	-	SIG_19	GND	GND
17	GND	GND	GND	GND	GND	GND	GND
18	GND	SIG_20	GND	-	SIG_21	GND	GND
19	GND	SIG_22	GND	-	SIG_23	GND	GND
20	GND	GND	GND	GND	GND	GND	GND
21	GND	SIG_24	GND	-	SIG_25	GND	GND
22	GND	SIG_26	GND	-	SIG_27	GND	GND
23	GND	GND	GND	GND	GND	GND	GND
24	GND	SIG_28	GND	-	SIG_29	GND	GND
25	GND	SIG_30	GND	-	SIG_31	GND	GND

XP3 Connector Pinout

XP3 Connector Pin Assignments


Pins	Signal
A	FAULTD
B	FAULTC
C	FAULTB
D	FAULTA
E	INST1-
F	INST1+
G	INST0-
H	INST0+




JR1 Connector Pinout

JR1 Connector Pin Assignments

Pins	Signal
1	FAULTD
5	FAULTC
2	FAULTB
6	FAULTA
3	INST1-
7	INST1+
4	INST0-
8	INST0+



JR2 Connector Pinout



CONFIGURATION



Caution Do not operate the DE9900 in a manner not specified in this document. Product misuse can result in a hazard. You can compromise the safety protection built into the product if the product is damaged in any way. If the product is damaged, return it for repair.



Contact

DEICO Head Office

Teknopark Ankara, Serhat Mah.,
2224 Cad., No:1 F Blok, Z-12,
Yenimahalle, Ankara, Türkiye

support@deico.com.tr

+90 312 395 68 44



www.deico.com.tr

